

# User Instruction

This instruction document is provided for end users in order to give information on use of spare parts ordered and received by themselves. For TV , end user accessible spare parts are Remote controller and External power supply.

## How to make your new Remote controller ready for use



1-Insert batteries into the slot on Remote controller. Please make sure about the direction (+/-) of the battery



2-Place plastic battery cover and then fix it to housing using the screw.

Please check the Instruction Book provided with your product in order to get information on “How to use the remote controller”

## Connecting External power supply to TV

Important Notice : This part is only for TV's provided with an external power supply



Make sure to connect the adapter socket to the correct port on the TV as shown.